

## **MINI 14/30 STOCK ASSEMBLY**

The following is a brief “how to” guide on assembling your Mini 14/30 into your new laminated stock.

First off, if you are changing from a synthetic stock to a laminate stock, you will need to purchase a few parts that do not come on the synthetic stocks. The three pieces you may need are:

- Stock Reinforcement (1)
- Stock Reinforcement Screws (2)
- Stock Reinforcement Lock Washers (2)

All of the parts are available from Ruger. The Stock Reinforcement needs to be ordered for your specific caliber (Mini 14 or Mini 30). It is not universal. The screws are made to fit either a Mini 14 or a Mini 30, and come blued or stainless.



<b>Stock Reinforcement</b>	<b>Stock Reinforcement Screw</b>	<b>Stock Reinforcement Lock Washer</b>
Ruger part #	Midway part #	Midway part #
MS00700 Mini 14-Blued	MS06900 Mini 14/30-Blued	MS08000 Mini 14/30
KMS00700 Mini 14-Stainless	KMS06900 Mini 14/30-Stainless	
MS20702 Mini 30-Blued		
KMS20702 Mini 30-Stainless		

When assembling your Mini into your new stock, the forend liner/cap assembly must be installed first.

Next, the Stock Reinforcement is installed. When the washers and screws are installed, do not tighten the screws all the way. This allows the receiver to “key” into the reinforcement piece easier. This is the next step.

Insert the front of your action into the forend liner/cap assembly. Next slide the receiver into the stock. The receiver will “key” into the Stock Reinforcement piece.

Once the barrel and receiver are installed, the Stock Reinforcement screws can be tightened.

Finally, the trigger assembly can be installed along with the handguard assembly.

Now you are ready to hit the range!